

# Drilling an Installation Hole for the OzoneOn with Side Spray

Tools required:

1. Cardboard box.
2. 1 ½" drill bit for stainless steel, this item used: <https://www.lowes.com/pd/Drill-America-1-1-2-in-Carbide-Tipped-Arbored-Hole-Saw/1001327878>
3. Cutting oil, this item used: <https://www.lowes.com/pd/Oatey-Cutting-Oil/4752939>
4. Electric drill

Procedure:



Decide where the hole will be located. Put a cardboard box over the location. This will prevent oil from splashing.



Put cutting oil over the location and put the drill on the screwdriver setting.



Begin to drill into the sink. Add cutting oil as needed. You may see smoke, this is normal. The smoke is created by the cutting oil.



Clean up the hole, remove the excess oil, then install the side spray.